


INSTALLAZIONE DELLE SPAZZOLE



Inserire la scanalatura di scorrimento presente sul lato destro del rullo nell'alloggiamento corrispondente della spazzola destra. Successivamente, premere il blocco di posizionamento sul lato sinistro del rullo fino a farlo scattare nella fessura della spazzola sinistra. Quando si sente un “click”, significa che la spazzola rotante è stata installata correttamente in sede.



UTILIZZO DELLE SPAZZOLE


L'apparecchio è dotato di due tipi di rullo spazzola intercambiabili, progettati per rispondere a diverse esigenze di pulizia.

Spazzola per lavaggio

Adatta alla maggior parte delle superfici domestiche, come piastrelle, marmo, gres, laminati, parquet e tappeti a pelo corto (non utilizzabile per tappeti a pelo lungo o a frange).

Tuttavia, prima dell'uso su pavimenti in parquet o superfici delicate, assicurarsi che la spazzola (L) sia perfettamente pulita, priva di residui o particelle abrasive che potrebbero graffiare il legno.

Una pulizia regolare del rullo è fondamentale per preservare l'integrità delle superfici più sensibili.




Si consiglia di utilizzare sempre la spazzola più adatta alla superficie da trattare e di conservarle separatamente, ben pulite, per garantirne la durata e l'efficacia nel tempo.

INSTALLING THE BRUSHES



Insert the sliding groove on the right side of the roller into the corresponding slot on the right brush. Next, press the positioning lock on the left side of the roller until it snaps into the slot on the left brush. A click indicates that the rotating brush is correctly installed.



USE OF BRUSHES


The appliance is equipped with two types of interchangeable brush rollers, designed to meet different cleaning needs.

Washing brush

Suitable for most household surfaces, such as tiles, marble, stoneware, laminate, parquet, and short-pile rugs (not suitable for long-pile or fringed rugs).

However, before using on parquet floors or delicate surfaces, make sure that the brush (L) is perfectly clean, free of residues or abrasive particles that could scratch the wood.

Regular cleaning of the roller is essential to preserve the integrity of more sensitive surfaces.



We recommend always using the most suitable brush for the surface to be treated, and storing them separately and thoroughly cleaned to ensure their durability and effectiveness over time.